SUMMARY

OPERATION NUMBER	DESCRIPTION
XM 901-000/1	Summary
XM 901-000/2	List of the electrical diagrams
XM 901-000/3	Parts list
XM 901-000/4	List of the wiring harnesses
XM 901-000/5	Colour coding
XM 901-000/6	Allocation of the fuses located under the bonnet (BB10)
XM 901-000/7	Allocation of the fuses in the passenger's compartment (PSF0)
XM 901-000/8	Positioning of multiplex control units
XM 901-000/9	Positioning of inter-connections
XM 901-000/10	Positioning of earth connections
XM 901-000/11	List of splices
XM 901-000/12	Multiplex diagnostic socket wiring
XM 901-000/13	Vehicle "awakened" diagram